

RAK4270 Breakout Board AT Command Manual

Introduction

The RAK4270 Breakout Board is designed to simplify LoRaWAN and LoRa point-to-point (P2P) communication. To integrate LoRa technology to your projects, RAK4270 has easy to use AT commands via UART communication interface. Through these AT commands, you can set the parameters needed for LoRaWAN and LoRa P2P communication.

In the RAK4270 Breakout Board, the serial communication is exposed on **UART1** port via **UART1_TX/PA9** and **UART1_RX/PA10**. The default parameters of the UART1 are **115200 / 8-N-1**. The firmware upgrade is also possible through this port.

In addition, RAK4270 board also exposed another serial port **UART2**, via **UART2_TX/PA2** and **UART2_RX/PA3**. You can use UART2 as alternative to UART1 when sending AT commands. You can also use UART2 when developing custom firmware via **RUI**. The default parameters of the UART2 are **115200 / 8-N-1**.

To get familiar with the pin distribution and other hardware details, refer to [RAK4270 Breakout Board Datasheet](#).

If only one UART is used in your project, it is recommended that you dedicate UART2 for AT commands and UART1 is reserved for firmware upgrade.

AT Command Syntax

The AT command is based on ASCII characters. A command begins with the prefix `at` and ends with `<CR><LF>` (i.e. `\r\n`). The maximum length is **255 characters** which includes the `<CR><LF>` characters at the end of the command. For the rest of the document, the `\r\n` part is omitted for the sake of clarity.

The AT commands can be classified in the following groups:

- **Read Command:** Reads the current configuration or status of the module. The command name and the list of parameters are separated by `=` character. The `<m>` parameter is separated with its associated value `<n>` by the `:` character.

```
at+get_config=<m>:<n>
```

- **Write Command:** Writes/Modifies the current configuration of the module. The command name and the list of parameters are separated by `=` character. The `<m>` parameter is separated with its associated value `<n>` by the `:` character.

```
at+set_config=<m>:<n>
```

- **Operational Commands:** Some commands are neither read nor write commands but are used to execute an action.

```
at+send=lora:<m>:<n> // Sends data through the LoRa transceiver.
```

- **Special Command:** The RAK4270 UART port has two operational modes: **Configuration Mode** (default mode) and **Data Transmission Mode**. Data transmission mode allows you to send ASCII payloads directly to the network server via UART without using any AT Command interface like `at+send=lora:X:YYY`. Data transmission mode is explained further on [Interface Type AT Command](#) section of this document.

 **NOTE:**

To enable data transmission mode, you need to input `at+set_config=device:uart_mode:<index>:<mode>` command. To switch back from data transmission mode to configuration mode (AT command default mode), the command to be entered is `+++` and does not contain terminators such as `\r` and `\n`.

After the command is executed by the module, a reply is sent back to the external MCU. In the case the command is successful, the usual reply has the following format:

```
OK [information]\r\n
```

 **NOTE:**

Only Read commands have information in the replied message, while Write commands do not have an informative description.

The firmware you developed, running in the external MCU, will expect at a minimum string of `Ok\r\n` after sending a successful command to the module. On the other hand, when the command is not successfully executed by the module, a reply will be received in the following format:

```
ERROR: [ErrCode]\r\n
```

Error Code Table

Error Code	Description
1	The last command received is an unsupported AT command.
2	Invalid parameter in the AT command.
3	There is an error when reading or writing the flash memory.
5	There is an error when sending data through the UART port.
80	The LoRa transceiver is busy, could not process a new command.
81	LoRa service is unknown. Unknown MAC command received by node. Execute commands that are not supported in the current state, such as sending <code>at+join</code> command in P2P mode.
82	The LoRa parameters are invalid.
83	The LoRa frequency is invalid.
84	The LoRa data rate (DR) is invalid.
85	The LoRa frequency and data rate are invalid.
86	The device hasn't joined into a LoRa network.
87	The length of the packet exceeded the maximum allowed by the LoRa protocol.
88	Service is closed by the server. Due to the limitation of duty cycle, the server will send "SRV_MAC_DUTY_CYCLE_REQ" MAC command to close the service.
89	This is an unsupported region code.
90	Duty cycle is restricted. Due to duty cycle, data cannot be sent at this time until the time limit is removed.
91	No valid LoRa channel could be found.
92	No available LoRa channel could be found.

Error Code	Description
93	Status is error. Generally, the internal state of the protocol stack is wrong.
94	Time out reached while sending the packet through the LoRa transceiver.
95	Time out reached while waiting for a packet in the LoRa RX1 window.
96	Time out reached while waiting for a packet in the LoRa RX2 window.
97	There is an error while receiving a packet during the LoRa RX1 window.
98	There is an error while receiving a packet during the LoRa RX2 window.
99	Failed to join into a LoRa network.
100	Duplicate downlink message is detected. A message with an invalid downlink count is received.
101	Payload size is not valid for the current data rate (DR).
102	Many downlink packets are lost.
103	Address fail. The address of the received packet does not match the address of the current node.
104	Invalid MIC is detected in the LoRa message.

General AT Command

1. at+version

This command is used to get the current firmware version number.

Operation	Command	Response
Read	at+version	OK <version number>

Parameter: None

Example:

```
at+version\r\nOK V3.3.0.14
```

2. at+help

This command is used to obtain all the AT commands supported by the current firmware.

Operation	Command	Response
Read	at+help	OK <all AT commands>

Parameter: None

Example:

```
at+help\r\nOK Device AT commands:  
at+version  
at+help  
at+set_config=device:restart  
at+set_config=device:sleep:X  
at+get_config=device:status  
at+set_config=device:uart:X:Y  
at+set_config=device:uart_mode:X:Y  
at+send=uart:X:YYY  
at+set_config=device:gpio:X:Y  
at+get_config=device:gpio:X  
at+get_config=device:adc:X  
  
LoRaWAN AT commands:  
at+set_config=lora:default_parameters  
at+join  
at+send=lora:X:YYY  
at+set_config=lora:region:XXX  
at+get_config=lora:channel  
at+set_config=lora:dev_eui:XXXX  
at+set_config=lora:app_eui:XXXX  
at+set_config=lora:app_key:XXXX  
at+set_config=lora:dev_addr:XXXX  
at+set_config=lora:apps_key:XXXX  
at+set_config=lora:nwks_key:XXXX  
at+set_config=lora:multicastenable:X  
at+set_config=lora:multicast_dev_addr:XXXX  
at+set_config=lora:multicast_apps_key:XXXX  
at+set_config=lora:multicast_nwks_key:XXXX  
at+set_config=lora:join_mode:X  
at+set_config=lora:work_mode:X  
at+set_config=lora:ch_mask:X:Y  
at+set_config=lora:class:X  
at+set_config=lora:confirm:X  
at+set_config=lora:dr:X  
at+set_config=lora:tx_power:X  
at+set_config=lora:adr:X  
at+get_config=lora:status  
at+set_config=lora:dutycycle_enable:X  
at+set_config=lora:send_repeat_cnt:X
```

LoRa P2P AT commands:

```
at+set_config=lorap2p:XXX:Y:Z:A:B:C  
at+set_config=lorap2p:transfer_mode:X  
at+send=lorap2p:XXX
```

3. **at+set_config=device:restart**

This command is used to restart the device.

Operation	Command	Response
Write	at+set config=device:restart	

Parameter: None

Example

```
at+set_config=device:restart\r\n
UART1 work mode: RUI_UART_NORMAL
Current work_mode:LoRaWAN, join_mode:ABP, Class: A
Initialization OK
```

4. **at+set_config=device:sleep: <status>**

This command is used to change the current state of the device between the sleep and the wake-up mode.

Operation	Command	Response
Write	at+set_config=device:sleep:<status>	OK <STATUS>
Parameter:		
status	0: wake up 1: sleep	

Example

```
at+set_config=device:sleep:1\r\nOK Sleep
```

```
at+set_config=device:sleep:0\r\nOK Wake Up
```

5. at+get_config=device:status

This command is used to obtain the current status of the device.

Operation	Command	Response
Read	at+get_config=device:status	OK <information>

Parameter: None

Example:

```
at+get_config=device:status\r\nOK Board Core:RAK4270\nMCU:STM32L071KB\nLoRa chip:SX1262
```

Interface Type AT Command

1. at+set_config=device:uart: <index>:<baud_rate>

This command is used to configure the baud rate for a UART port.

Operation	Command	Response
Write	at+set_config=device:uart:<index>:<baud_rate>	OK

Parameter:

index

UART Number (1 or 2)

baud_rate

UART Baud rate: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200

Example:

```
at+set_config=device:uart:1:115200\r\nOK
```

2. **at+set_config=device:uart_mode: <index>:<mode>**

This command is used to set the UART operation from AT **configuration mode** to **data transmission mode**.

During **data transmission mode**, all standard AT Commands will not work and the data that you sent to UART will go directly to the network server as ASCII payload with `\r\n`. If you input `AZ`, the network server will receive an uplink hex value of `415A0D0A`. This means `A= 0x41`, `Z= 0x5A`, `\r= 0x0D` and `\n= 0x0A`.

NOTE:

To switch back from data transmission mode to configuration mode, use `+++` (`+++` without `\r\n`).

Operation	Command	Response
Write	<code>at+set_config=device:uart_mode:<index>:<mode></code>	OK

Parameter:

index UART Number (1 or 2)

mode UART Mode: Only 1 can be selected, which means the UART is set to data transmission mode.

Example:

```
at+set_config=device:uart_mode:1:1\r\nOK
```

```
+++  
OK
```

3. at+send=uart: <index>:<data>

This command is used to send data over a UART port.

Operation	Command	Response
Write	at+send=uart:<index>:<data>	OK

Parameter:

index UART Number (1 or 2)

The data you want to send.

data The maximum length of data is **250 characters**, equivalent to 255 — the length of `at+...` — the length of `\r\n`.

Example:

```
at+send=uart:1:12345\r\nOK
```

4. at+get_config=device:gpio: <pin_num>

This command is used to obtain the voltage level status of a GPIO pin on a module.

Operation	Command	Response
Read	at+get_config=device:gpio:<pin_num>	OK <status>

Parameter:

	Pin index of the module
pin_num	(GPIO pins available on this Breakout board are Pin 3, Pin 6, Pin 9, Pin 10, Pin 16, and Pin 17 of the RAK4270 module)
status (Return Value)	0: Low Voltage Level 1: High Voltage Level




Figure 1: GPIO Pinout of the RAK4270 Breakout board

Example:

```
at+get_config=device:gpio:3\r\n
OK 1
```

5. **at+set_config=device:gpio: <pin_num>:<status>**

This command is used to set the voltage level state (high or low) of a GPIO pin on a module.

Operation	Command	Response
Write	<code>at+set_config=device:gpio:<pin_num>:<status></code>	OK

Parameter:

pin_num	Pin index of the module (GPIO pins available on this Breakout board are Pin 3, Pin 6, Pin 9, Pin 10, Pin 16, and Pin 17 of the RAK4270 module) Please refer to Figure 1.
status	0: Low Voltage Level 1: High Voltage Level

Example:

```
at+set_config=device:gpio:3:0\r\n
OK
```

6. `at+get_config=device:adc: <pin_num>`

This command is used to obtain the voltage level of an ADC pin of the module.

Operation	Command	Response
Read	<code>at+get_config=device:adc:<pin_num></code>	OK <voltage>

Parameter:

pin_num	ADC pin index of the module (ADC pin available on this Breakout board is assigned to Pin 3 of the RAK4270 module)
Voltage (Return Value)	Voltage, Unit: mV




Figure 2: ADC Pinout of the RAK4270 Breakout board

Example:

```
at+get_config=device:adc:3\r\nOK 1663mV
```

LoRaWAN Type AT Command

1. at+join

This command is used to join a LoRaWAN network.

Operation	Command	Response
	at+join	OK Join Success

Parameter: None

Example

```
at+join\r\nOK Join Success
```

2. at+send=lora: <port>:<data>

This command is used to send data via LoRaWAN.

Operation	Command	Response
	at+send=lora:<port>:<data>	OK

Parameter:

port Sending port of LoRa. The value range is 1-223.

data The sending data format is in hexadecimal format. The possible values are between **00-FF**. The module will internally cast every two characters into a byte before sending it to the LoRa transceiver. The maximum length varies depending on the band frequency and DR (LoRaWAN standard). Refer to [Appendix III](#).

Example:

When sending data as unconfirmed uplink:

```
at+send=lora:1:5A00\r\nOK
```

When sending data as confirmed uplink:

```
at+send=lora:1:5A00\r\nOK\nat+recv=0,-105,-12,0
```

NOTE

- When sending a confirmed message, you will receive an ACK response, i.e. `at+recv=....`. The `0, -105, -12,0` stands for:
 - `0` : For the LoRa port;
 - `-105` : For the RSSI;
 - `-12` : For the SNR;
 - `0` : For the length of the data (no valid data in ACK).
- When sending an unconfirmed message, sometimes the gateway will send MAC commands to nodes, and the node will also receive `at+recv=....`.

3. `at+set_config=lora:region: <region>`

This command is used to set the appropriate working frequency band.

Operation	Command	Response
Write	<code>at+set_config=lora:region:<region></code>	<code>OK</code>

Parameter:

`region` EU433, CN470, IN865, EU868, US915, AU915, KR920, AS923. The default is EU868.

Example:

```
at+set_config=lora:region:EU868\r\nOK
```

NOTE

In the AS923 frequency band, the supported frequency plan is "as2" and the dwell time is set to 1.

4. `at+get_config=lora:channel`

This command is used to read all the LoRa channel information given the current region configured on the board.

Operation	Command	Response
Read	at+get_config=lora:channel	OK <channel information>

Parameter: None

Example (EU868 region):

at+get_config=lora:channel\r\nn
OK *0,on,868100000,0,5; *1,on,868300000,0,5; *2,on,868500000,0,5; 3,off,0,0,0; 4,off,0,0,0; 5,off,0,0,0; 6,off,0,0,0;

NOTE

With *0,on,868100000,0,5 as an example, the following is the channel parameter analysis:

- * at the beginning if the channel is open;
 - 0 is the channel ID;
 - on indicates the current status of the channel;
 - 868100000 is the actual frequency of the channel, unit is Hz;
 - 0,5 indicates the DR of the channel, DR0~DR5.

5. **at+set_config=lora:ch_mask: <channel_number>:<status>**

This command is used to enable (on) or disable (off) a channel in the current region.

Operation	Command	Response
Write	at+set config=lora:ch mask:<channel number>;<status>	OK

Parameter:

channel_number

Channel number

status

0: off
1: on**Example:**

```
at+set_config=lora:ch_mask:0:0\r\nOK
```

6. at+set_config=lora:dev_eui: <dev_eui>

This command is used to set the Device EUI parameter for the LoRaWAN OTAA mode.

Operation	Command	Response
Write	<code>at+set_config=lora:dev_eui:<dev_eui></code>	OK

Parameter:

dev_eui Device EUI

Example:

```
at+set_config=lora:dev_eui:3530353064377716\r\nOK
```

7. at+set_config=lora:app_eui: <app_eui>

This command is used to set the Application EUI parameter for the LoRaWAN OTAA mode.

Operation	Command	Response
Write	<code>at+set_config=lora:app_eui:<app_eui></code>	OK

Parameter:

app_eui Application EUI

Example:

```
at+set_config=lora:app_eui:0000000000000001\r\nOK
```

8. at+set_config=lora:app_key: <app_key>

This command is used to set the Application Key parameter for the LoRaWAN OTAA mode.

Operation	Command	Response
Write	at+set_config=lora:app_key:<app_key>	OK

Parameter:

app_key Application Key

Example:

```
at+set_config=lora:app_key:841986913ACD00BBC2BE2479D70F3228\r\nOK
```

9. at+set_config=lora:dev_addr: <dev_addr>

This command is used to set the Device Address parameter for the LoRaWAN ABP mode.

Operation	Command	Response
Write	at+set_config=lora:dev_addr:<dev_addr>	OK

Parameter:

dev_addr

Device Address

Example:

```
at+set_config=lora:dev_addr:260125D7\r\nOK
```

10. at+set_config=lora:apps_key: <apps_key>

This command is used to set the Application Session Key parameter for the LoRaWAN ABP mode.

Operation	Command	Response
Write	at+set_config=lora:apps_key:<apps_key>	OK

Parameter:

apps_key Application Session Key

Example:

```
at+set_config=lora:apps_key:841986913ACD00BBC2BE2479D70F3228\r\nOK
```

11. at+set_config=lora:nwks_key: <nwks_key>

This command is used to set the Network Session Key parameter for the LoRaWAN ABP mode.

Operation	Command	Response
Read	at+set_config=lora:nwks_key:<nwks_key>	OK

Parameter:

nwks_key

Network Session Key

Example:

```
at+set_config=lora:nwks_key:69AF20AEA26C01B243945A28C9172B42\r\nOK
```

12. at+set_config=lora:multicastenable: <IsEnable>

This command is used to enable or disable the multicast feature.

Operation	Command	Response
Write	at+set config=lora:multicastenable:<IsEnable>	OK

Parameter:

IsEnable 0: disable
1: enable
The default is disable.

Example:

```
at+set_config=lora:multicastenable:1\r\nOK
```

13. **at+set_config=lora:multicast_dev_addr: <multicast_dev_addr>**

This command is used to set the Device Address for the multicast feature.

Operation	Command	Response
Write	at+set_config=lora:multicast_dev_addr:<multicast_dev_addr>	OK

Parameter:

multicast_dev_addr	Multicast Device Address
--------------------	--------------------------

Example:

```
at+set_config=lora:multicast_dev_addr:260111fd\r\nn  
OK
```

14. at+set_config=lora:multicast_apps_key: <multicast_apps_key>

This command is used to set the Application Session Key for the multicast feature.

Operation	Command	Response
Write	at+set_config=lora:multicast_apps_key:<multicast_apps_key>	OK

Parameter:

multicast_app_addr	Multicast Application Session Key
--------------------	-----------------------------------

Example:

```
at+set_config=lora:multicast_apps_key:F13DDFA2619B10411F02F042E1C0F356\r\nn  
OK
```

15. at+set_config=lora:multicast_nwks_key: <multicast_nwks_key>

This command is used to set the Network Session Key for the multicast feature.

Operation	Command	Response
Write	at+set_config=lora:multicast_nwks_key:<multicast_nwks_key>	OK

Parameter:

multicast_nwks_key

Multicast Network Session Key

Example:

```
at+set_config=lora:multicast_nwks_key:1D1991F5377C675879C39B6908D437A6\r\nOK
```

16. **at+set_config=lora:join_mode:** <mode>

This command is used to switch the LoRaWAN access mode between the OTAA and the ABP mode.

Operation	Command	Response
Write	at+set config=lora:join mode:<mode>	OK

Parameter:

mode Activation mode
0: OTAA
1: ABP
The default is OTAA.

Example:

```
at+set_config=lora:join_mode:1\r\nOK
```

17. **at+set_config=lora:class: <class>**

This command is used to set LoRaWAN class to Class A, Class B, or Class C.

Operation	Command	Response
Write	at+set config=lora:class:<class>	OK

Parameter:

class
0: Class A
1: Class B (Not supported at this time)
2: Class C
The default is Class A.

Example:

```
at+set_config=lora:class:0\r\nOK
```

18. at+set_config=lora:confirm: <type>

This command is used to set the type data to be sent: Confirmed/Unconfirmed.

Operation	Command	Response
Write	at+set_config=lora:confirm:<type>	OK

Parameter:

type
0: unconfirm Type
1: confirm Type
The default is unconfirm type.

Example:

```
at+set_config=lora:confirm:0\r\nOK
```

19. at+set_config=lora:dr: <dr>

This command is used to set the data rate (DR) of LoRa.

Operation	Command	Response
Write	at+set_config=lora:dr:<dr>	OK

Parameter:

dr The data rate of LoRa is related to the current region. In most of the LoRa areas, it is common to use 0 to 5. Detailed reference can be made to LoRaWAN 1.0.2 specification.

20. at+set_config=lora:tx_power: <tx_power>

This command is used to set the RF transmission power level of the LoRa transceiver.

Operation	Command	Response
Write	at+set_config=lora:tx_power:<tx_power>	OK

Parameter:

Refer to [Appendix II](#) for possible values of tx_power. The table of Appendix II is based on LoRaWAN 1.0.2 specification. LoRa transmit power level varies depending on frequency band.

tx_power If the resulting TX power is higher than the capability of LoRa Radio, the output power will be based on the max TX power of the LoRa Radio in the module. For RAK4270 module, the max TX power is 22dBm. Take note of this when using regional bands with MaxEIRP higher than 22dBm like US915, AU915 and IN865 whose MaxEIRP is 30dBm.

The default setting is 0.

Example:

```
at+set_config=lora:tx_power:0\r\n
OK
```

21. at+set_config=lora:adr: <status>

This command is used to turn on/off the ADR feature of the LoRa communication.

Operation	Command	Response
Write	at+set_config=lora:adr:<status>	OK

Parameter:

status 0: Turn off
1: Turn on
The default is on.

Example:

```
at+set_config=lora:adr:0\r\nOK
```

22. at+get_config=lora:status

This command is used to get all the information related to the current LoRa status, except channel information.

Operation	Command	Response
Read	at+get config=lora:status	OK <lora status detail>

Parameter: None

Example:

```
at+get_config=lora:status\r\nOK Work Mode: LoRaWAN\nRegion: EU868\nSend_interval: 600s\nAuto send status: false.\nMulticastEnable: true.\nMulti_Dev_Addr: 260111FD\nMulti_Apps_Key: F13DDFA2619B10411F02F042E1C0F356\nMulti_Nwks_Key: 1D1991F5377C675879C39B6908D437A6\nJoin_mode: OTAA\nDevEui: 000000000000888\nAppEui: 000000000000888\nAppKey: 00000000000088800000000000000000888\nClass: C\nJoined Network:false\nIsConfirm: unconfirm\nAdrEnable: true\nEnableRepeaterSupport: false\nRX2_CHANNEL_FREQUENCY: 869525000, RX2_CHANNEL_DR:0\nRX_WINDOW_DURATION: 3000ms\nRECEIVE_DELAY_1: 1000ms\nRECEIVE_DELAY_2: 2000ms\nJOIN_ACCEPT_DELAY_1: 5000ms\nJOIN_ACCEPT_DELAY_2: 6000ms\nCurrent Datarate: 4\nPrimeval Datarate: 4\nChannelsTxPower: 0\nUpLinkCounter: 0\nDownLinkCounter: 0
```

23. **at+set_config=lora:dutycycle_enable: <status>**

This command is used to enable or disable the Duty Cycle feature.

Operation	Command	Response
Write	at+set_config=lora:dutycycle_enable:<status>	OK

Parameter:

status 0: disable
1: enable
The default is disable.

Example:

```
at+set_config=lora:dutycycle_enable:1\r\nOK
```

24. **at+set_config=lora:send_repeat_cnt: <num>**

This command is used to set the number of retransmitting attempts on an uplink message. When activated, the board will resend a message if its corresponding ACK (downlink) is not received after sending a confirmed uplink message. The default value is 0, which means that the board will not resend any message by default.

Operation	Command	Response
Write	<code>at+set_config=lora:send_repeat_cnt:<status></code>	OK

Parameter	Description
num	Number of retries, up to 7. The default is 0.

Example:

```
at+set_config=lora:send_repeat_cnt:1\r\nOK
```

25. **at+set_config=lora:default_parameters**

This command is used to restore OTAA, ABP, multicast related network access parameters set at the factory, including dev_eui, app_eui, etc.

Operation	Command	Response
Write	at+set_config=lora:default_parameters	OK

Parameter: none

Example:

```
at+set_config=lora:default_parameters\r\n
OK
```

LoRa P2P Type AT Command

1. at+set_config=lora:work_mode: <mode>

This command is used to switch the LoRa work mode between the LoRaWAN and the LoRa P2P mode. This command will cause the module to restart.

Operation	Command	Response
Write	at+set_config=lora:work_mode:<mode>	

Parameter:

mode	Work Mode of LoRa 0: LoRaWAN 1: LoRa P2P
------	--

The default is LoRaWAN mode.

Example:

```
at+set_config=lora:work_mode:1\r\n
UART1 work mode: RUI_UART_NORMAL
Current work_mode:P2P
Initialization OK
```

2. **at+set_config=lorap2p: <frequency>:<spreadfact>:<bandwidth>:<codingrate>:<preamlen>:<power>**

This command is used to set the relevant parameters of LoRa P2P mode and is only valid when the LoRa work mode is changed to LoRa P2P before.

Operation	Command	Response
Write	at+set_config=lorap2p:<frequency>:<spreadfact>:<bandwidth>:<codingrate>:<preamlen>:<power>	OK

Parameter:

frequency	Frequency, the unit is Hz The default is 869525000 Hz.
spreadfact	Spreading factor The default is 12.
bandwidth	0: 125 kHz 1: 250 kHz 2: 500 kHz
codeingrate	The default is 0. 1: 4/5 2: 4/6 3: 4/7 4: 4/8
preamble	The default is 1.
power	Preamble Length. 5~65535 The default is 8.
	TX power. The unit is in dBm. 5~20 The default is 20.

Example:

```
at+set_config=lorap2p:869525000:12:0:1:8:20\r\nOK
```

3. at+set_config=lorap2p:transfer_mode: <mode>

This command is used to switch the state of the LoRa transceiver between sending and receiving state, and it is only valid when the LoRa mode is set to LoRa P2P before.

Operation	Command	Response
Write	at+set_config=lorap2p: transfer_mode:<mode>	OK

Parameter:

mode	1: receiver mode 2: sender mode
	The default is sender mode.

Example:

```
at+set_config=lorap2p:transfer_mode:1\r\nOK
```

4. at+send=lorap2p: <data>

This command is used to send data in LoRa P2P mode, and it is only valid when the LoRa mode is set to LoRa P2P before.

Operation	Command	Response
Send	at+send=lorap2p:<data>	OK

Parameter:

data	The data to be sent, and the format is hexadecimal.
------	---

Example:

```
at+send=lorap2p:1234\r\n
OK
```

In LoRa P2P mode, the receiving node receives the data and outputs the data in the following format:

```
at+recv=<RSSI>,<SNR>,<Data Length>:<Data>
```

Appendix I: Data Rate by Region

EU868/EU433/AS923

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	LoRa: SF7 / 250 kHz	11000
7	FSK: 50 kbps	50000
8 ~ 15	RFU	

CN470/KR920

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6 ~ 15	RFU	

US915

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF10 / 125 kHz	980
1	LoRa: SF9 / 125 kHz	1760
2	LoRa: SF8 / 125 kHz	3125
3	LoRa: SF7 / 125 kHz	5470
4	LoRa: SF8 / 500 kHz	12500
5 ~ 7	RFU	
8	LoRa: SF12 / 500 kHz	980
9	LoRa: SF11 / 500 kHz	1760
10	LoRa: SF10 / 500 kHz	3900
11	LoRa: SF9 / 500 kHz	7000
12	LoRa: SF8 / 500 kHz	12500
13	LoRa: SF7 / 500 kHz	21900
14 ~ 15	RFU	

AU915

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	LoRa: SF8 / 500 kHz	12500
7	RFU	RFU
8	LoRa: SF12 / 500 kHz	980
9	LoRa: SF11 / 500 kHz	1760
10	LoRa: SF10 / 500 kHz	3900
11	LoRa: SF9 / 500 kHz	7000
12	LoRa: SF8 / 500 kHz	12500

IN865

Data Rate	Configuration	Indicative Physical Bit Rate [bit/s]
0	LoRa: SF12 / 125 kHz	250
1	LoRa: SF11 / 125 kHz	440
2	LoRa: SF10 / 125 kHz	980
3	LoRa: SF9 / 125 kHz	1760
4	LoRa: SF8 / 125 kHz	3125
5	LoRa: SF7 / 125 kHz	5470
6	RFU	RFU
7	FSK: 50 kbps	50000
8 ~ 15	RFU	RFU

Appendix II: TX Power by Region

EU868

By default, MaxEIRP is considered to be +16 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

US915

By default, MaxEIRP is considered to be +30 dBm based on LoRa Alliance specification. However, the module's max TX power is only up to 22 dBm.

TXPower	Configuration (Conducted Power)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3 ~ 9	-
10	10 dBm
11 ~ 15	RFU

AU915

By default, MaxEIRP is considered to be +30 dBm based on LoRa Alliance specification. However, the module's max TX power is only up to 22 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1 ~ 10	MaxEIRP - 2*TXPower
11 ~ 15	RFU

KR920

By default, MaxEIRP is considered to be +14 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

AS923

By default, MaxEIRP shall be 16 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

IN865

By default, MaxEIRP is considered to be +30 dBm based on LoRa Alliance specification. However, the module's max TX power is only up to 22 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8	MaxEIRP - 16 dB
9	MaxEIRP - 18 dB
10	MaxEIRP - 20 dB
11 ~ 15	RFU

CN470

By default, MaxEIRP is considered to be +19.15 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6	MaxEIRP - 12 dB
7	MaxEIRP - 14 dB
8 ~ 15	RFU

EU433

By default, MAxEIRP is considered to be +12.15 dBm.

TXPower	Configuration (EIRP)
0	MaxEIRP
1	MaxEIRP - 2 dB
2	MaxEIRP - 4 dB
3	MaxEIRP - 6 dB
4	MaxEIRP - 8 dB
5	MaxEIRP - 10 dB
6 ~ 15	RFU

Appendix III: Maximum Transmission Load by Region

NOTE

In the following list, M is the length with MAC header and N is the maximum usable payload size for the user data without MAC header.

EU868

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

US915

DataRate	M	N
0	19	11
1	61	53
2	133	125
3	250	242
4	250	242
5 ~ 7	Not Defined	Not Defined
8	61	53
9	137	129
10	250	242
11	250	242
12	250	242
13	250	242
14 ~ 15	Not Defined	Not Defined

AU915

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	Not Defined	Not Defined
8	61	53
9	137	129
10	250	242
11	250	242
12	250	242
13	250	242
14 ~ 15	Not Defined	Not Defined

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6 ~ 15	Not Defined	Not Defined

AS923

DataRate	Uplink MAC Payload Size (M)		Downlink MAC Payload Size (M)	
	UplinkDwellTime = 0	UplinkDwellTime = 1	DownlinkDwellTime = 0	DownlinkDwellTime = 1
0	59	N/A	59	N/A
1	59	N/A	59	N/A
2	59	19	59	19
3	123	61	123	61
4	250	133	250	133
5	250	250	250	250
6	250	250	250	250
7	250	250	250	250
8 ~ 15	RFU		RFU	

IN865

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

CN470

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6 ~ 15	Not Defined	Not Defined

EU433

DataRate	M	N
0	59	51
1	59	51
2	59	51
3	123	115
4	250	242
5	250	242
6	250	242
7	250	242
8 ~ 15	Not Defined	Not Defined

Appendix IV: Pin Description of RAK4270 Breakout Board

The pin definition of the RAK4270 Breakout Board can be reviewed in the [Pin Definition](#) section of the Datasheet.

Listed are the summary of pins of the RAK4270 Breakout Board:

 **NOTE:**

Not all pins of RAK4270 module are exposed on the RAK4270 Breakout board header connectors. Below are the pins available on the RAK4270 Module that are on this Breakout board. For complete RAK4270 module pinouts information, refer to the [datasheet](#).

1. About the UART pin:

- Pin 5 (RX1) and Pin 4 (TX1) are reserved for UART1.
- Pin 1 (RX2) and Pin 2 (TX2) are reserved for UART2.

- During sleep, Pin 5 (RX1) and Pin 1 (RX2) are configured as external interrupt mode, an internal pull-down resistor, and rising edge trigger wake-up, respectively.
2. **About the SWD Debug Pin:** Pin 7 (SWDIO) and Pin 8 (SWCLK) are used for SWD debug port.
3. **About the Power Pin:** The power pins on the RAK4270 module includes VDD on Pin 20 and Ground pins (GND) are on the Pin 11, Pin 13, Pin 14, and Pin 19.
4. **About the Reset Pin:** The reset pin on the RAK4270 module is Pin 18 (MCU_NRST).
5. **About the ADC Pin:** The ADC pin on the RAK4270 module is assigned to Pin 3 (UART2_DE).
6. **About the GPIO Pins:** The GPIO pins available on the RAK4270 module are the following:

- Pin 3 (UART2_DE/PA1)
- Pin 6 (UART1_DE/PA12)
- Pin 9 (I2C_SCL/PB6)
- Pin 10 (I2C_SDA/PB7)
- Pin 16 (PB4)
- Pin 17 (PA8)

NOTE

If you want to use RAK4270 Breakout Board to make a product, you should understand how to upgrade the RAK4270 firmware in future. As mentioned, the firmware of the RAK4270 Breakout Board can be upgraded through the SWD or UART1. Both requires a general-purpose PC.